

Megatronix – UPS – Sensor Interface for Factory Alarm System

Description:

The interface unit allows the ability to add a sensor to a vehicle's factory alarm system. Most factory systems are not equipped with any type of sensor (such as shock, glass, or radar). The interface module receives the trigger information from the sensor and then supplies a selectable positive or negative output to trigger a factory hood, trunk, or door pin input. This unit features the standard 4-pin sensor connector for use with the sensor unit. A status indicator LED and override switch is supplied for the operation of valet and test modes.

Basic Operation:

- 1) Turn the ignition 'OFF'
- 2) Sensor turns on 30 seconds after ignition is turned off
- 3) The LED flashes once every 3 seconds
- 4) LED for sensor interface illuminates while sensor is triggered for visual indication

Valet Mode:

Valet mode allows the use of factory alarm system without the shock sensor capability. Valet mode does not affect the functions of the factory alarm system and only disables the sensor from triggering the factory alarm system.

Enter Valet mode:

- 1) Turn the ignition 'ON'
- 2) Press and hold the valet button for 2 seconds to enter valet mode
- 3) When entering valet mode, the LED flashes 2 times and remains off until you exit valet mode
- 4) The LED will always be off in valet mode

Exit Valet mode:

- 1) Turn the ignition 'ON'
- 2) Press and hold the valet button for 2 seconds to exit from valet mode
- 3) When exiting valet mode, the LED flashes 1 time, and the sensor interface operates normally

Sensor Silent Test Mode:

Test mode allows the sensor interface LED to illuminate when the sensor is triggered, to easily adjust the sensor without triggering the factory alarm, preventing the sounding of the vehicle's horn:

- 1) Turn the ignition 'OFF'
- 2) System must not be in valet mode
- 3) Close all doors and windows
- 4) Press the override switch 5 times
 - a) LED stops flashing
 - b) System is in sensor test mode
- 5) Test sensor
 - a) Tap vehicles body panels with palm of your hand or a rubber mallet
 - b) To increase sensitivity, rotate adjustment 1/8th of a turn clockwise.
 - c) Repeat until desired setting is reached
 - d) Red LED will illuminate when impact is detected
- 6) Exit sensor test mode
 - a) Turn the ignition 'ON' or wait 2 minutes so sensor test mode exits automatically

