


# MEGATRONIX

## NBS6 – Rechargeable Battery Backup Car Alarm Siren



### WIRING

**Red Wire** – Power: Connect this wire to power 12 volts.

**Black Wire** – Ground: Connect this wire to chassis ground.

**White Wire** – Positive trigger: Connect this wire to positive (+) siren output of alarm.

**Blue Wire** – Negative trigger: Connect this wire to negative (–) siren output of alarm.

**Note:** Use white or blue wire (Not both together) depending on alarm siren output polarity. Most alarm systems use a positive trigger siren output. Some alarm systems have a secondary siren output that is usually negative triggered.

### Operation:

Turn key to green dot to activate siren. Turn siren key to red dot to disable siren. Siren sounds when alarm system triggers its siren output wire.

**MEGATRONIX**  
CALIFORNIA, U.S.A.

**WWW.MEGATRONIXUSA.COM**

COPYRIGHT © MEGATRONIX. ALL RIGHTS RESERVED.